



Dialog Plus

UNINTERRUPTIBLE POWER SUPPLY

- ON LINE -

700 VA ÷ 3000 VA

Manuale d'uso

User's manual

Bedienungsanleitung

Manuel d'utilisateur

Manual de usuario





INTRODUCTION

Thanks you for choosing our product.

Our manufacturer are renowned specialists in the development and production of uninterruptible power supplies (UPS). The UPS in this range are high quality products, designed and built with care in order to give you the best performance.

This equipment can be installed by anyone, subject to **CAREFULLY AND THOROUGHLY READING THIS MANUAL.**

The manual contains detailed instructions on how to use and install the UPS.

For information on using and getting the best performance from your UPS, this manual should be kept safely in the vicinity of the UPS and CONSULTED BEFORE TAKING ANY ACTION ON THE UPS.

© Reproduction of any part of this manual, including partial, is strictly prohibited without the prior consent of the manufacturer.
For the purpose of improving it, the manufacturer reserves the right to modify the product described herein at any time and without notice.

Microsoft, Windows, and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.

PRESENTATION	40
VIEW OF THE UPS	41
Front Views	41
Rear Views	42
VIEW OF LED INDICATOR PANEL	44
INSTALLATION AND Use	45
OPENING THE PACKAGING AND CHECKING THE CONTENTS	45
CONNECTIONS AND SWITCHING ON FOR THE FIRST TIME	46
Connection to the Net/Tel protection device	46
SWITCHING ON FROM MAINS POWER	46
SWITCHING ON FROM BATTERY	47
SWITCHING OFF THE UPS	47
LED INDICATOR PANEL	48
OVERLOADS ON THE UPS	49
COMMUNICATION PORTS	50
RS232 serial port	50
Communication Slot	51
SOFTWARE	51
Monitoring and control software	51
Configuration Software	51
UPS CONFIGURATION	52
ALARMS AND INDICATORS	53
UPS STATUS REPORTS TABLE	53
UPS FAILURE REPORTS TABLE	54
PROBLEM SOLVING	55
TECHNICAL SPECIFICATIONS	56

PRESENTATION


The new **Dialog Plus** family of UPS has been designed to offer versatility and reliability.

They use ON LINE technology, which means that the AC power for the load is converted to DC and then back to AC again to ensure a perfectly sinusoidal output, the frequency and voltage of which are established by microprocessor digital control and are independent of the input power source. This family of UPS has an automatic by-pass device that switches the load to mains power in the event of overvoltages or any other power problems to guarantee continuous power supply even in critical conditions.

This family of UPS is available in two versions:

- ❑ **Standard**: with batteries inside of the UPS
- ❑ **ER**: without batteries inside, but including a powerful battery charger (max 8A). This series must be combined with an external battery box, so it is indicated for long autonomy time.


The figures below show the various product versions:




		Dialog Plus 70	Dialog Plus 100/100ER	Dialog Plus 150	Dialog Plus 200/200ER	Dialog Plus 300/300ER
Nominal power	[VA]	700	1000	1500	2000	3000
Output nominal voltage	[Vac]	220/230/240				
Dimensions HxWxD	[mm]	231x158x400	231x158x400	231x158x500	340x192x460	340x192x460
Weight	[Kg]	12	14/8	19	34/14	35/14

VIEW OF THE UPS**Front Views**

Models: 700-1000-1500VA




Models: 2000-3000VA




1. LED indicator panel
2. ON button
3. OFF button

Rear Views


Dialog Plus 70




Dialog Plus 100 / 100 ER / 150



Dialog Plus 200




Dialog Plus 200 ER




1. RS232 serial communication port
2. Cooling fans
3. Telephone/modem protection
4. Input thermal protection
5. IEC mains input plug

Dialog Plus 300 / 300 ER



6. IEC output sockets (max 10A)
7. Communication expansion slot
8. Battery expansion connector
9. IEC 16A output socket
10. Output socket fuse boxes

VIEW OF LED INDICATOR PANEL




- ① Load level indicator
- ② Battery level indicator
- ③ Mains mode indicator
- ④ Battery mode indicator / Battery low indicator
- ⑤ Battery failure indicator
- ⑥ Load powered by bypass indicator
- ⑦ “Fault/Stand-by” indicator

OPENING THE PACKAGING AND CHECKING THE CONTENTS


The first thing to do after opening the packaging is to check the contents

The packaging should contain the following:


- ❑ UPS




- ❑ RS232 serial cable




- ❑ IEC 10A(or 16A) Power cord





- ❑ IEC 16A Power cord set (only for model 3000VA)



- ❑ 2 IEC 10A connection cables



- ❑ User manual + CD-ROM with software



INSTALLATION AND USE

This chapter describes the operations to be carried out to prepare the UPS.

WARNING: *the instructions below should be followed scrupulously for your personal safety and that of the product.*



BEFORE CARRYING OUT THE FOLLOWING SEQUENCE OF OPERATIONS, MAKE SURE THAT THE UPS IS COMPLETELY SWITCHED OFF AND IS NOT CONNECTED TO THE MAINS OR TO ANY LOAD.



CONNECTIONS AND SWITCHING ON FOR THE FIRST TIME

- 1) Connect the power cable supplied with the UPS to the IEC input socket.
- 2) Connect the UPS power cable to mains power supply.
- 3) After a few moments the UPS will be activated, a beep will be emitted and the “Fault/Stand-by” LED will light. The UPS is now in the stand-by state: this means that the UPS is in a minimum consumption condition. The microcontroller is powered and carries out supervision tasks and autodiagnosics; the batteries are charging; the outputs are disconnected; the cooling fans are operating; everything is ready for the UPS to be started up.
- 4) Connect the load/s to be powered to the sockets on the rear of the UPS using the IEC-IEC cables supplied or a cable with maximum length of 10 meters.
N.B.: do not connect any loads that absorb more than 10A to the 10A IEC sockets. These loads should be connected exclusively to the 16A IEC socket when this is available.

Connection to the Net/Tel protection device

A telephone/modem or network cable can be connected to the modular RJ-45/RJ11 connectors located on the rear of the UPS that protect against overvoltages. A telephone extension cable is required for this type of connection.

N.B.: *The connection is optional. The Net/Tel protection is active even when the UPS is turned off or disconnected from mains power.*

Warning: *The device that protects against overvoltage on the telephone line may not work if it is not installed correctly. Ensure that the telephone wall cable is inserted in the connector marked “IN” and that the cable of the unit to be protected (telephone, modem, network card, etc.) is inserted in the connector marked “OUT”.*

Warning: *The overvoltage protection device is only for indoor use. Do not connect telephone wires during a storm.*

N.B.: *The protection device limits the effects of an overvoltage but does not guarantee overall protection.*

SWITCHING ON FROM MAINS POWER

- 1) Press the ON button for at least one second (until a beep sounds). Once it is released, all the LEDs come on for 1 second and a beep sounds. The UPS then runs a short test on the battery voltage and mains power status. In normal conditions, after this test, only the “mains” LED, load level and battery level indicators stay lit (if different lights or audio signals appear/occur, consult the table in the “Alarms and Indicator” Chapter for further details).
- 2) Switch on the loads connected to the UPS.
Only for the first time you switch on: after about 30 sec., check that the UPS is working correctly by:
 1. Simulating a black-out by removing the mains power cable
 2. The load must continue to receive power, the “battery mode” indicator should light up and the UPS should beep every 4 seconds.
 3. Reconnect the power cable. Normal mains power operation should be restored.

SWITCHING ON FROM BATTERY

- 1) When mains power is not available, press the ON button for about 1 second (until a beep sounds and then release it). All the icons on the indicator panel light up for 1 second and a beep sounds. A test is run on the battery voltage and, if all is normal, only the “Battery mode”, load level and battery level indicators stay on accompanied by an intermittent beep.
- 2) Switch on all the loads connected to the UPS.

SWITCHING OFF THE UPS

When mains power is available, to switch off the UPS hold the OFF button down (for about 2 seconds) until a beep sounds and then release it. UPS returns to standby mode and only the “Fault/Standby” indicator starts flashing.

When mains power is not available and time function is not on, to switch off the UPS hold the OFF button down (for about 2 seconds) until a beep sounds and then release it. The buzzer sounds for 1 second and all LEDs light till the power source is shutdown completely.

When mains power is not available and time function is on, to switch off the UPS hold the OFF button down (for about 5 seconds) until the 2nd beep sounds and then release it. The buzzer sounds for 1 second and all LEDs light till the power source is shutdown completely.

ADDITIONAL FUNCTIONS PERFORMED ON THE FRONT PANEL

UPS in stand by mode

- ❑ To **cancel a software programmed shutdown**⁽¹⁾ keep the “ON” key pressed down until the **2nd beep** is heard and then release immediately (approx. 5 sec), or keep the “OFF” key pressed down until a **beep** is heard and then release immediately (approx. 2 sec).

UPS in mains power mode

- ❑ To **mute the intermittent alarm** on the UPS during the final phase of a software scheduled shutdown, hold the ON key down (for about 1 seconds) until a **1st beep** sounds and then release it
- ❑ To **cancel a software programmed shutdown**⁽¹⁾ keep the “ON” key pressed down until the **2nd beep** is heard and then release immediately (approx. 5 sec), or keep the “OFF” key pressed down until a **beep** is heard and then release immediately (approx. 2 sec).
- ❑ To run a **battery test**, hold the ON key down (for about 5 seconds) until the **third beep** is heard and then release it. At this point the test starts. The LEDs flash cyclically on the display panel. Once the test is completed, if the batteries are in good condition, the UPS will return to mains mode with the usual indications, or, if the batteries are faulty or discharged, the “battery failure” light comes on accompanied by a beep (consult the table in the Alarms and Indicator Chapter for further details)
- ❑ To see the approximate input **mains voltage** value of the UPS on the battery indicator, press the ON button for at least 10 seconds until the **4th beep** sounds. Release the button and the battery level indicator shows the normal battery voltage value.

UPS in battery mode








- ❑ To **mute the intermittent alarm** that sounds when the UPS is in battery mode, hold the ON button down (for about 1 second) until the **1st beep** is heard and then release it.
N.B. the UPS cannot be muted if the batteries are running low (1 beep every second).
- ❑ To **cancel a software programmed shutdown**⁽¹⁾, hold the ON button down (for about 2 seconds) until the **2nd beep** is heard and then release it.

⁽¹⁾ For more details on the functions that can be activated via software, consult the software manual on the CD-Rom provided.

INSTALLATION AND USE

LED INDICATOR PANEL

This chapter gives a detailed description of all LED indicator panel.


ICON	STATUS	DESCRIPTION
	Red / Steady	Indicates an fault
	Red / Flashing	The UPS is in stand-by mode
	Green / Steady	The UPS is operating on mains power
	Green / Flashing	<ul style="list-style-type: none"> The UPS is operating off the bypass The voltage input is out of the accepted range
	Green / Steady	The UPS is operating in battery mode and will beep at regular intervals.
	Green / Flashing	When operating off battery power, the UPS signals that it is about to switch off due to end of discharge. In this state, it beeps at regular intervals of 1 sec. (see Tab. 1)
	Red / Steady	Indicates battery failure
	Yellow / Steady	The loads connected to the UPS are powered by the bypass
	Green / Active	Represents the estimated percentage of battery charge by 5 LEDs (see table 2)
		Hold the ON button down for at least 10 seconds to show the input voltage value (see table 3)
	Green – Red / Active	Indicates the % of load applied to the UPS in relation to the nominal value. the last icon indicates overload (see table 4)

Tab. 1	
Battery status	LED - battery working -
Normal	•
Low	◆

- LED with steady light on
- ◆ LED with flashing light on (1 flash per second)

Battery level	Battery LED bar				
	1	2	3	4	5
0%~20%	•				
20%~40%	•	•			
40%~60%	•	•	•		
60%~80%	•	•	•	•	
80%~100%	•	•	•	•	•

Input Voltage	Battery LED bar				
	1	2	3	4	5
190V~200V	•				
200V~230V	•	•			
230V~250V	•	•	•		
250V~260V	•	•	•	•	
>260V	•	•	•	•	•

Load level	Load LED bar				
	25	50	75	100	
0~5%					
5~25%	•				
25%~50%	•	•			
50%~75%	•	•	•		
75%~102%	•	•	•	•	
>102%	•	•	•	•	•

- LED on with steady light
- ♦ LED with flashing light on (1 flash per second)

OVERLOADS ON THE UPS

The following table shows how the UPS reacts when mains and battery overloads occur and indicates the time that the UPS will remain powered.

OVERLOAD LEVEL	LOAD POWER TIMES (off mains)	LOAD POWER TIME (off battery)
$102\% < \text{Load} \leq 109\%$	Switches to bypass after 30 min	Shutdown after 30 min (if battery back up time allows)
$110\% \leq \text{Load} \leq 130\%$	Switches to bypass after 30 sec	Shutdown after 30 sec
$130\% < \text{Load} \leq 150\%$	Switches to bypass after 10 sec	Shutdown after 10 sec
$\text{Load} > 150\%$	Switches to bypass after 0.5 sec	Shutdown after 0.5 sec
Short circuit	Immediate shutdown	Immediate shutdown

INSTALLATION AND USE

After switching over to the bypass due to overloading, the UPS powers the loads off mains power and a continuous alarm will sound. By reducing the load within the 102% threshold, the UPS returns to normal operating mode.

When the overload level is too high, the input thermal protection is activated and the UPS will be completely shutdown.

To restore normal operation, reduce the load so that it is within the 102% threshold and restore thermal protection by pressing the relevant button on the rear of the UPS and then switch on again.

To restore normal operation following failure due to overloading (continuous beep and load not powered), reduce the load so that it falls within the 102% threshold. Hold the OFF button down until the continuous beep stops and then release it. Wait until the UPS is completely shutdown and then switch on again.


COMMUNICATION PORTS

The UPS has the following communication ports (see *UPS views*):

- RS232 serial port
- COMMUNICATION SLOTS: expansion slots for additional interface cards

RS232 serial port

The RS232 serial port allows the connection of a PC (COM port) by means of a pin-to-pin serial cable (provided⁽¹⁾).



⁽¹⁾ If a different cable is used, it should be of the pin-to-pin type with a max. length of 3 metres.

⁽²⁾ Optoisolated contact max. +35Vdc / 15mA.

⁽³⁾ SD: With UPS in operation from battery, the UPS will perform a complete shutdown when +5~15Vdc is applied (between PIN 3 and PIN 5) for at least 20 seconds.

Communication Slot

All UPS come with an expansion slot for optional communication boards so that the unit is compatible with the main communication standards.

Some examples:

- Serial port duplexer
- Ethernet network agent with TCP/IP, HTTP and SNMP protocols
- RS232 + RS485 port with JBUS / MODBUS protocol

For more details on the options available, visit the manufacturer's web site.

SOFTWARE

The CD-Rom provided includes two software programmes that allow the user to perform UPS monitoring, control and configuration operations.

Monitoring and control software

The Powershield 2 software ensures efficient and intuitive *UPS management*, by displaying all the most important information such as input voltage, applied load, battery capacity, etc.

It can also automatically execute programmed shutdown/start-up operations, shutdown of the O.S., sending of e-mails, sms and network messages when specific user-selected events occur.

Installation Operations:

- Connect the UPS RS232 communication port to a COM port on the PC using the serial cable provided.
- Insert the CD-Rom and select the operating system required.
- Follow the installation instructions. .
- For more detailed information on the installation and use of the software, refer to the software manual in the *Manuals* folder on the CD-Rom provided.

Visit the manufacturer's web site to check whether a more recent version of the software is available.

Configuration Software

UPSTools software allows the user to configure the UPS and provides a full view of the system parameters and status through the RS232 serial port.

Refer to the paragraph ***UPS Configuration*** for a list of the possible configurations available.

Installation Operations:

- Connect the UPS RS232 communication port to the COM port on the PC using the serial cable provided.
- Follow the installation instructions given in the software manual in the *UPSTools* folder on the CD-Rom provided.

Visit the manufacturer's web site to check whether a more recent version of the software is available.

UPS CONFIGURATION

The following table lists all the possible configurations available so as to best adapt the UPS to user requirements. The configuration may be modified only by using the configuration software provided (UPSTools).

FUNCTION	DESCRIPTION	PREDEFINED	POSSIBLE CONFIGURATIONS
Automatic Restart	Automatic restart when mains power returns	Enabled.	<ul style="list-style-type: none"> • Disabled • Enabled
Battery low alarm	Remaining battery charge level setting for the battery low alarm	3 min.	1 - 99 in steps of 1 minute
Output frequency	Allows the user to select the output frequency.	50Hz	<ul style="list-style-type: none"> • 50Hz • 60Hz • Auto (depending on the UPS input frequency it will operate at 50 or 60 Hz)
Output voltage	Allows the user to select the output voltage	230 Vac	<ul style="list-style-type: none"> • 220 Vac • 230 Vac • 240 Vac
Bypass voltage threshold	Selects the voltage range accepted for switching over to bypass	Low: 180V High: 264V	Low: 180 ÷ 200 in steps of 1V High: 250 ÷ 264 in steps of 1V
Battery capacity	Allow the user to set the capacity of battery	Standard: 7.2Ah ER: 65Ah	The user must set the capacity of battery if the actual capacity is different from the default value.

UPS STATUS REPORTS TABLE

The following table describes the light and audio indicators that appear/sound during normal UPS operation.

UPS Status		Load level					Battery level					Mains LED	Battery LED	By-pass LED	Battery failure LED	Failure/ Fault LED	Audio Alarm
		1	2	3	4	5	1	2	3	4	5						
Standby																◆	
Bypass		Load level					Battery level					◆		●			
Line		Load level					Battery level					●					
Battery	Battery normal	Load level					Battery level						●				1 beep every 4s
	Battery low												◆				1 beep per sec.
Battery test	Test phase	Load level					Battery level					◆ (cyclically)					
	Test over: If the battery < test voltage											●			●		6 beeps (2 per second)
During countdown of auto restart	Mains normal											◆				◆	
	Mains abnormal												◆			◆	
During countdown of shutdown	Line mode	Load level					Battery level					●	◆				1 beep every 4s (During the final phase of the shutdown)
	Battery mode												◆				

- LED on with steady light
- ◆ LED on with flashing light (1 flash per second)

ALARMS AND INDICATORS

UPS FAILURE REPORTS TABLE

The following table describes the light and audio signals that appear/sound to indicate a fault.

UPS Status		Load level					Battery level					Mains LED	Battery LED	Bypass LED	Battery failure LED	Failure/Fault LED	Audio Alarm
		1	2	3	4	5	1	2	3	4	5						
Mains overload	Alarm phase						Battery level					•					2 beeps per sec.
	Switch over to bypass due to overload	•	•	•	•	•						◆		•		•	continuous beep
Battery overload	Alarm phase	•	•	•	•	•	Battery level						•				2 beeps per second
	Failure															•	continuous beep
Capacitor bank voltage fault		Load level							•							•	continuous beep
Output short circuit		Load level						•			•					•	continuous beep
Inverter fault		Load level						•								•	continuous beep
Overheating fault		Load level					•									•	continuous beep
Overloaded Battery fault	Bypass	Load level										◆		•		•	4 long beeps at 1-second intervals
	Line						◆	◆	◆	◆	◆	◆				•	
	Standby															•	
Battery charge fault	Bypass	Load level										◆	◆	•		•	1 beep per second
	Line											•	◆			•	
	Standby												◆			•	
Fan fault		Load level					•				•					•	1 beep per second
Input Relay fault		Load level								•						•	Continuous beep

- LED on with steady light
- ◆ LED on with flashing light (1 flash per second).

Very often incorrect UPS operation is not caused by a fault but by common problems, difficulties or carelessness.

The table below gives some useful information to help the user solve the most frequent problems.

PROBLEM	POSSIBLE CAUSE	SOLUTION
THE DISPLAY PANEL DOES NOT LIGHT UP	THE POWER CABLE IS NOT CONNECTED	Check that the power cable is connected correctly.
	NO MAINS POWER (BLACK-OUT)	Check that there is voltage in the socket to which the UPS is connected (try with a table lamp)
	INPUT THERMAL PROTECTION IS ACTIVE	Reset the protection by pressing the button on the rear of the UPS (CIRCUIT BREAKER). <u>N.B.</u> : Check that there is no UPS output overload.
THE PANEL IS ON BUT THE LOAD IS NOT POWERED	UPS IN STANDBY MODE	Press the ON button on the front panel to power the loads.
	THE LOAD IS NOT CONNECTED	Check the connection to the load.
THE UPS IS IN BATTERY MODE EVEN THOUGH MAINS POWER IS AVAILABLE	INPUT THERMAL PROTECTION ACTIVE	Reset the protection by pressing the button on the rear of the UPS (CIRCUIT BREAKER). <u>N.B.</u> : Check that there is no UPS output overload.
	THE INPUT VOLTAGE IS OUTSIDE THE ACCEPTED VALUES FOR OPERATION OFF MAINS POWER	Mains power problem. Wait until the input voltage returns to acceptable limits; the UPS will automatically return to mains power mode.
A CONTINUOUS BEEP SOUNDS AND THE LOAD INDICATOR IS ALL LIT UP	THE LOAD CONNECTED TO THE UPS IS TOO HIGH	Reduce the load so that it falls within the 102% threshold.
“BATTERY FAILURE” APPEARS ON THE DISPLAY	THE BATTERIES MUST BE REPLACED	Contact the Technical Support centre
A CONTINUOUS BEEP SOUNDS AND THE LED PANEL SHOWS ONE OF THE INDICATIONS LISTED IN THE “FAULTS TABLE”	A FAULT HAS BEEN FOUND ON ONE OR MORE LOADS POWERED BY THE UPS	Disconnect all the loads and reconnect them one at a time to identify the faulty load.
	A MALFUNCTION HAS OCCURRED	If possible disconnect the load, switch the UPS off and on again. If the problem remains, call the Technical Support centre.

TECHNICAL SPECIFICATIONS

MODELS	Dialog Plus 70	Dialog Plus 100	Dialog Plus 100 ER
--------	----------------	-----------------	--------------------

INPUT

Nominal voltage	[Vac]	220 / 230 / 240		
Transfer Voltage Range				
- low line transfer	[load %] [Vac]	Based on load percentage 100-80% = 160 ± 5 80-70% = 140 ± 5 70-60% = 120 ± 5 60-0% = 110 ± 5		
-Low line comeback	[Vac]	170 ± 5		
-High line transfer	[Vac]	300 ± 5		
-High line comeback	[Vac]	285 ± 5		
Nominal frequency	[Hz]	50 / 60		
Nominal current	[A]	3.8	5	6.2
Power factor		≥ 0.97		
Input protection		7A thermal breaker		

BYPASS

Accepted voltage range for switch over	[Vac]	180 - 264		
Accepted frequency range for switch over		Selected frequency ±5 %		
Time taken for switch over	[msec]	Typically: 2 - Maximum: 4		

BATTERY

N° batteries / V / Ah		2 / 12 / 7.2	3 / 12 / 7.2	--
Recharge time	[h]	4 h to 80% of full charge		--

OUTPUT

Nominal voltage	[Vac]	220 / 230 / 240		
Static variation (4)		1.5%		
Dynamic variation (5)		≤ 5% in 20 msec		
Wave form		Sinusoidal		
Voltage distortion @ linear load		≤ 3%		
Voltage distortion @ distorting load (3)		≤ 6%		
Frequency (6)		50 – 60 Hz ± 0.2Hz		
Synchronisation range		46-54Hz / 56-64Hz		
Current crest factor		3 : 1		
Nominal power (3)	[VA]	700	1000	
Nominal power	[W]	490	700	

OTHER VALUES

OTHER VALUES			
Current leakage to ground	[mA]	≤ 1.2	
AC/AC efficiency		86%	88%
Ambient temperature (7)	[°C]	0 – 40	
Humidity		< 90% non condensing	
Protections		Excessive battery discharge - overcurrent – short circuit – overvoltage - undervoltage - thermal	
Safety certifications		EN62040-1-1 and EEC 73 / 23, 93/68 specifications	
EMC Compliance		EN 50091 - 2 cl. B and EEC 89/336, 92/31, 93/68 specifications	
Noise		< 45 dB(A) at 1 Mt.	
Dimensions H x W x D	[mm]	231 x 158x 400	
Weight	[Kg]	12	14 8

TECHNICAL SPECIFICATIONS

MODELS	Dialog Plus 150	Dialog Plus 200	Dialog Plus 200 ER
--------	-----------------	-----------------	--------------------

INPUT

Nominal Voltage	[Vac]	220 / 230 / 240		
Transfer Voltage Range				
-Low line transfer	[load %] [Vac]	Based on load percentage 100-80% = 160 ± 5 80-70% = 140 ± 5 70-60% = 120 ± 5 60-0% = 110 ± 5		
-Low line comeback	[Vac]	170 ± 5		
-High line transfer	[Vac]	300 ± 5		
-High line comeback	[Vac]	285 ± 5		
Nominal frequency	[Hz]	50 / 60		
Nominal current	[A]	7.2	10	13.4
Power factor		≥ 0.97		
Input protection		10A thermal breaker	12A thermal breaker	16A thermal breaker

BYPASS

Accepted voltage range for switch over	[Vac]	180 – 264		
Accepted frequency range for switch over		Selected frequency ±5 %		
Time taken for switch over	[msec]	Typically: 2 - Maximum: 4		

BATTERY

N° batteries / V / Ah		4 / 12 / 7.2	8 / 12 / 7.2	--
Recharge time	[h]	4 h to 80% of full charge		--

OUTPUT

Nominal voltage	[Vac]	220 / 230 / 240		
Static variation (4)		1.5%		
Dynamic variation (5)		≤ 5% in 20 msec		
Wave form		Sinusoidal		
Voltage distortion @ linear load		≤ 3%		
Voltage distortion @ distorting load (3)		≤ 6%		
Frequency (6)		50 ± 0.2Hz autosense		
Synchronisation range		46-54Hz		
Current crest factor		3 : 1		
Nominal power (3)	[VA]	1500	2000	
Nominal power	[W]	1050	1400	

OTHER VALUES

Current leakage to ground	[mA]	≤ 1.2		
AC/AC efficiency		88%		
Ambient temperature (7)	[°C]	0 – 40		
Humidity		< 90% non condensing		
Protections		Excessive battery discharge - overcurrent – short circuit – overvoltage - undervoltage - thermal		
Safety certifications		EN62040-1-1 and EEC 73 / 23, 93/68 specifications		
EMC compliance		EN 50091 - 2 cl. B and EEC 89/336, 92/31, 93/68 specifications		
Noise		< 45 dB(A) at 1 Mt.		
Dimensions H x W x D	[mm]	231 x 158x 500	340 x 192 x 460	
Weight	[Kg]	19	34	14

TECHNICAL SPECIFICATIONS

MODELS	Dialog Plus 300	Dialog Plus 300 ER
--------	-----------------	--------------------

INPUT

Nominal voltage	[Vac]	220 / 230 / 240
Transfer Voltage Range		
-Low line transfer	[load %] [Vac]	Based on load percentage 100-80% = 160 ± 5 80-70% = 140 ± 5 70-60% = 120 ± 5 60-0% = 110 ± 5
-Low line comeback	[Vac]	170 ± 5
-High line transfer	[Vac]	300 ± 5
-High line comeback	[Vac]	285 ± 5
Nominal frequency	[Hz]	50 / 60
Nominal current	[A]	14.4 16
Power factor		≥ 0.97
Input protection		16A thermal Breaker

BYPASS

Accepted voltage range for switch over	[Vac]	180 - 264
Accepted frequency range for switch over		Selected frequency ±5 %
Time taken for switch over	[msec]	Typically: 2 - Maximum: 4

BATTERY

N° batteries / V / Ah	8 / 12 / 7.2	--
Recharge time	[h] 4 h to 80% of full charge	--

OUTPUT

Nominal voltage	[Vac]	220 / 230 / 240
Static variation (4)		1.5%
Dynamic variation (5)		≤ 5% in 20 ms
Wave form		Sinusoidal
Voltage distortion at linear load		≤ 3%
Voltage distortion at distorting load (3)		≤ 6%
Frequency (6)		50 ± 0.2Hz autosense
Synchronisation range		46-54Hz
Current crest factor		3 : 1
Nominal power (3)	[VA]	3000
Nominal power	[W]	2100

OTHER VALUES

Current leakage to ground	[mA]	≤ 1.2
AC/AC efficiency		88%
Ambient temperature (7)	[°C]	0 – 40
Humidity		< 90% non condensing
Protection		Excessive discharge of batteries – overcurrent – short circuit – overvoltage – undervoltage – thermal
Safety certifications		EN 62040-1-1 and EEC 73 / 23, 93/68 specifications
EMC compliance		EN 50091 - 2 cl. B and EEC 89/336, 92/31, 93/68 specifications
Hold-up time	[msec]	≥ 40
Noise		< 45 dB(A) at 1 Mt.
Dimensions H x W x D	[mm]	340 x 192 x 460
Weight	[Kg]	35 14

- ⁽¹⁾ at nominal load, minimum voltage of 164 Vac, battery charging
- ⁽²⁾ at nominal load, nominal voltage of 230Vac, battery charging
- ⁽³⁾ Second appendix M5 of the EN50091-1-1 specifications
- ⁽⁴⁾ Mains/Battery at load: 0% -100%
- ⁽⁵⁾ at Mains / battery / mains at resistive load: 0% / 100% / 0%
- ⁽⁶⁾ If the mains frequency falls within $\pm 5\%$ of the selected value, the UPS is synchronised with mains voltage. If the frequency is outside the accepted values or if the UPS is in battery mode, the selected frequency is adopted $\pm 0.1\%$.
- ⁽⁷⁾ 20 - 25 °C to ensure a longer battery life.



UPS MANUFACTURING s.r.l.

I – 37048 S.Pietro di Legnago (VR)

Italy – Viale Europa, 7 – ZAI

Tel. +39 0442 635811 – Fax +39 0442 629098

www.riello-ups.com - riello@riello-ups.com